



* Hold down the SOS button for **5 seconds** to send the emergency signal to the organizer



Turn on / Turn off button

1 How to turn on the device?

The turn on/turn off button must be pressed during some seconds until the red light switches on. Then, the other lights will start to blink.

2 When to turn it on?

Device must be turned on at least **15 minutes** before the start time in an open area.

3 How to turn off the device?

The turn on/turn off button must be pressed during some seconds until the red light starts to blink.

* The light blinking may last about 90 seconds.

4 When to turn it off?

Device must be turned off at least **5 minutes** after the arrival to finish line.